













NRG ICEFREE | CUP ANEMOMETER

SENSOR WIRING TABLE

Sensor Model	Sensor Pin		Kintech Cable Colors		Orbit 360			EOL Zenith		
					Section	Terminal	Type	Section	Terminal	
	(+)	Signal		White	Frequency Channels		Signal	Anemometer Inputs		
	(-)	Reference		Brown	Frequency Channels		(-)	Anemometer Inputs		
		Shield		Yellow Green	Power Input			BAT		
		Heating (+)		Brown	Independent power supply 24 AC/DC					
		Heating (-)		Blue						

HOW TO CONFIGURE IN ATLAS

Open Atlas and go to the data logger you are working on. Scroll to the “channels” section and select the following type and model:

- Group: Frequency channels
- Sensor Type: Anemometer
- Sensor Model: **NRG ICEFREE**

HOW TO CONFIGURE IN EOL MANAGER

Open EOL Manager and go to the data logger you are working on. Open the “inputs” tab and select the following type and model:

- Group: Anemometers/Frequency
- Type: Anemometer
- Model: **NRG ICEFREE**

Last modified: 08.11.2019

For more information please contact support@kintech-engineering.com or visit our website www.kintech-engineering.com

