











## SECONDWIND C3 | CUP ANEMOMETER

### SENSOR WIRING TABLE

Sensor Model	Sensor Pin		Kintech Cable Colors		Orbit 360			EOL Zenith	
					Section	Terminal	Type	Section	Terminal
	(+)	Signal		White	Frequency Channels		Signal	Anemometer Inputs	
	(-)	Reference		Brown	Frequency Channels		(-)	Anemometer Inputs	
		Shield		Yellow Green	Power Input			BAT	

#### HOW TO CONFIGURE IN ATLAS

Open Atlas and go to the data logger you are working on. Scroll to the “channels” section and select the following type and model:

- Group: Frequency channels
- Sensor Type: Anemometer
- Sensor Model: **NRG 40C / 40H**

#### HOW TO CONFIGURE IN EOL MANAGER

Open EOL Manager and go to the data logger you are working on. Open the “inputs” tab and select the following type and model:

- Group: Anemometers/Frequency
- Type: Anemometer
- Model: **NRG 40/40H**

Last modified: 06.02.2020

For more information please contact [support@kintech-engineering.com](mailto:support@kintech-engineering.com) or visit our website [www.kintech-engineering.com](http://www.kintech-engineering.com)

