











WINDSENSOR P2546C | CUP ANEMOMETER

SENSOR WIRING TABLE

Sensor Model	Sensor Pin		Kintech Cable Colors		Orbit 360			EOL Zenith	
					Section	Terminal	Type	Section	Terminal
 P2546C-OPR	Internal Pin	Signal		White	Frequency Channels		Signal	Anemometer Inputs	
	External Pin	Ref.		Brown	Frequency Channels		(-)	Anemometer Inputs	
		Shield		Yellow Green	Power Input			BAT	

HOW TO CONFIGURE IN ATLAS

Open Atlas and go to the data logger you are working on. Scroll to the “channels” section and select the following type and model:

- Group: Frequency channels
- Sensor Type: Anemometer
- Sensor Model: **K620A / ORNYTION 107 / P2546C**

HOW TO CONFIGURE IN EOL MANAGER

Open EOL Manager and go to the data logger you are working on. Open the “inputs” tab and select the following type and model:

- Group: Anemometers/Frequency
- Type: Anemometer
- Model: **RISO P2546**

