









































THIES 5.4106.00.X0X | PLUVIOMETER

CABLE RECOMMENDATION

Signal cable up to 150m: **4x0.5 mm² + shield**. For longer cable, please consult sensor manufacturer.

SENSOR WIRING TABLE

Sensor Model	Sensor Pin Manufacturer Cable Colors			Kintech Cable Colors		Orbit 360			EOL Zenith	
						Section	Terminal	Type	Section	Terminal
 5.4106.00.001 5.4106.00.000	2		Brown		Brown	Power Input	(-)		BAT	
	3		Green		White	Analog Channels		Signal	Analog Inputs	
	4		Yellow		Yellow	Frequency Channels		5V	Anemometer Inputs	 
	1		White		Green	Power Input			BAT	
					Yellow Green	Power Input	BAT		BAT	

Sensor Model	Sensor Pin Manufacturer Cable Colors			Kintech Cable Colors		Orbit 360			EOL Zenith	
						Section	Terminal	Type	Section	Terminal
 5.4106.00.100	2		Brown		Brown	Power Input	(-)		BAT	
	4		Yellow		White	Analog Channels		Signal	Analog Inputs	
	5		Grey		Yellow	Frequency Channels		5V	Anemometer Inputs	 
	1		White		Green	Power Input			BAT	
					Yellow Green	Power Input	BAT		BAT	

Note: 5.4106.00.001: Output 0VDC: no precipitation, Output 5VDC: precipitation.

5.4106.00.000: Output 0VDC: precipitation, Output 5VDC: no precipitation.

5.4106.00.100: Output 0VDC: no precipitation, Output 5VDC: precipitation.

REQUIRED DATA LOGGER VERSION

Minimum data logger required: **ORBIT 360 BASIC PLUS**.

Minimum **firmware** required: **any**.



THIES 5.4106.00.X0X | PLUVIOMETER

HOW TO CONFIGURE IN ATLAS

Start Atlas and open the data logger you are working on. Now go to *Site settings* and scroll down to the *Channels* section and select the following type and model:

- Group: Analog channels
- Sensor Type: Voltage
- Sensor Model: **Volts**
- Slope: 1
- Offset: 0

Important! Please make sure you are working with the latest version of Atlas. To check for new updates click the *Check for updates* button in the left-hand menu located in the main dashboard.

HOW TO CONFIGURE THIS SENSOR ON SITE

We recommend performing the entire sensor configuration using Atlas at the office before installing sensors onsite. Once the sensor is correctly setup in Atlas, use the *Upload settings* tool, to upload the sensor configuration to the data logger.

In case you are already on site and need to configure the sensor directly on the data logger, follow these steps:

1. Turn on the data logger.
2. Using the keypad on the data logger, navigate the menu until you see *Sensor model*, then click the “right arrow” on the keypad.
3. Now scroll down to the channel you are going to connect the sensor to, and click the “right arrow” on the keypad.
4. Now click “Set” on the keypad and scroll up in the menu to set the sensor model type according to the table here below. Once you have found the correct sensor model, click the “right arrow” key twice to select it and save.
5. Click the “left arrow” several times to go back to the main menu.

Data logger model	Firmware version	Sensor model type on data logger		
		Magnitude	Number	Name
ORBIT 360	any	Pluviometer	01	milliVolts
EOL ZENITH	any	Pluviometer	01	miliVolts

Keep in mind: if the sensor channel has been configured as *milliVolts*, the output values on data logger display will always be shown in *milliVolts*. Remember to fill in both the slope and the offset for the pressure sensor to see real sensor values in *mbar* in your datasets during a real-time connection with the data logger (from either Atlas or Atlas Mobile).

HOW TO CONFIGURE IN EOL MANAGER

Open EOL Manager and go to *Settings* of the data logger you are working on. Open the *Inputs* tab and select the following type and model:

- Group: Analog Inputs
- Sensor Type: Voltmeter
- Sensor Model: **Generic Voltmeter**
- Slope: 1
- Offset: 0



Last modified: 24.09.2021