













SENSOR WIRING TABLE

Sensor Model	Manufacturer Cable Colors			Kintech Connector R: 4k7, C: 100nF			Orbit 360			EOL Zenith		
							Section	Terminal	Type	Section	Terminal	
		Green Yellow	Ref	B			Black	Frequency Channels		(-)	Anemometer Inputs	
								Frequency Channels				Signal
		Red Black	Signal	A		Green	Frequency Channels		5V	Anemometer Inputs		

HOW TO CONFIGURE IN ATLAS

Open Atlas and go to the data logger you are working on. Scroll to the “channels” section and select the following type and model:

- Group: Frequency channels
- Sensor Type: Pluviometer
- Sensor Model: **Pluviometer 0.2mm**

HOW TO CONFIGURE IN EOL MANAGER

Open EOL Manager and go to the data logger you are working on. Open the “inputs” tab and select the following type and model:

- Group: Anemometers/Frequency Inputs
- Type: Pluviometer
- Model: **Pluviometer 0.2mm**

