








K307 | TEMPERATURE

SENSOR WIRING TABLE

Sensor Model	Sensor Pin		Kintech Cable Colors		Orbit 360			EOL Zenith	
					Section	Terminal	Type	Section	Terminal
	Us (-)	Supply (-)	●	Black	Analog Channels		(-)	Analog Inputs	
	Temp (+)	Temperature	●	Green	Analog Channels		Signal	Analog Inputs	
	Us (+)	Supply (+)	●	Red	Analog Channels	50 54 58 62	5 π	Extra Analog	
		Shield	●	Yellow Green	Power Input	BAT	⏏	Analog Inputs	
								BAT	⏏

HOW TO CONFIGURE IN ATLAS

Open Atlas and go to the data logger you are working on. Scroll to the “channels” section and select the following type and model:

- Group: Analog channels
- Sensor Type: Temperature
- Sensor Model: **K307**

HOW TO CONFIGURE IN EOL MANAGER

Open EOL Manager and go to the data logger you are working on. Open the “inputs” tab and select the following type and model:

- Group: Analog Inputs
- Type: Temperature
- Model: **EOL 307**

Last modified: 11.11.2019

For more information please contact support@kintech-engineering.com or visit our website www.kintech-engineering.com

