



























NRG 40 | CUP ANEMOMETER

SENSOR WIRING TABLE

Sensor Model	Sensor Pin		Kintech Cable Colors		Orbit 360			EOL Zenith	
					Section	Terminal	Type	Section	Terminal
 NRG 40C	(+)	Signal		White	Frequency Channels		Signal	Anemometer Inputs	
	(-)	Reference		Brown	Frequency Channels		(-)	Anemometer Inputs	
		Shield		Yellow Green	Power Input			BAT	

Sensor Model	Sensor Pin		Kintech Cable Colors		Orbit 360			EOL Zenith	
					Section	Terminal	Type	Section	Terminal
 NRG 40H	(+)	Signal		White	Frequency Channels		Signal	Anemometer Inputs	
			 R:4k7		Frequency Channels		5V	Anemometer Inputs	
	(-)	Reference		Brown	Frequency Channels		(-)	Anemometer Inputs	
	U(s)	Supply (+)		Green	Power Input			BAT	
		Shield		Yellow Green	Power Input			BAT	

HOW TO CONFIGURE IN ATLAS

Open Atlas and go to the data logger you are working on. Scroll to the “channels” section and select the following type and model:

- Group: Frequency channels
- Sensor Type: Anemometer
- Sensor Model: **NRG 40/40**

HOW TO CONFIGURE IN EOL MANAGER

Open EOL Manager and go to the data logger you are working on. Open the “inputs” tab and select the following type and model:

- Group: Anemometers/Frequency
- Type: Anemometer
- Model: **NRG 40/40H**

Last modified: 07.11.2019

For more information please contact support@kintech-engineering.com or visit our website www.kintech-engineering.com

