

















SENSOR WIRING TABLE

Sensor Model	Sensor Pin		Manufacturer Cable Colors		Orbit 360			EOL Zenith	
					Section	Terminal	Type	Section	Terminal
  Output: 0...1V -40...+60°C 0...100%	SIG (-)	Ref		Brown	Analog Channels		(-)	BAT	
	Temp (+)	Temp		Green	Analog Channels		Signal	Analog Inputs Extra Analog	
	Us (+)	Supply (+)		White	Analog Channels		*(+)	BAT	
	RH (+)	RH		Yellow	Analog Channels		Signal	Analog Inputs Extra Analog	
	Shield			Yellow Green	Power Input	BAT		BAT	

**Note 1:** (+)\* = Bat+ with limited current (12mA). Only 1 sensor can be connected.

HOW TO CONFIGURE IN ATLAS

Open Atlas and go to the data logger you are working on. Scroll to the “channels” section and select the following type and model:

- Group: Analog channels
- Sensor Type: Temperature
- Sensor Type: Relative Humidity
- Sensor Model: **K846TH**

HOW TO CONFIGURE IN EOL MANAGER

Open EOL Manager and go to the data logger you are working on. Open the “inputs” tab and select the following type and model:

- Group: Analog Inputs
- Type: Temperature
- Type: Rel. Humidity
- Model: **K846TH**

Last modified: 05.06.2020