



DATASHEET K360V+ WIND VANE

The next generation high precision wind vane is designed for use in wind resource assessment and built from high strength anodized aluminium and durable enforced polycarbonate.

The K360V+ sensor has no dead band and a resolution of just 0.35° and accuracy of +/- 1.4° .



DESCRIPTION

The K360V+ sensor is a high precision wind vane with continuous 360° rotation and no dead band and a resolution of just 0.35°. The K360V+ is designed for use in wind resource assessment, solar resource assessment as well as meteorology and environmental monitoring and features a very low starting threshold of less than 0.4 m/s, an accuracy of +/- 1.4° and is built from high strength anodized aluminium and polycarbonate for harsh climatic conditions. The wind vane is designed for mounting on a 25 mm (or 1") diameter tube.

Optional three per box packages to reduce the transpost costs. The sensor complies with the specifications of the World Meteorological Organization (WMO-No.8)

Main characteristics:

• High accuracy of +/- 1.4°

- No dead band
- High resolution of 0.35°
- High quality materials
- Threshold < 0.4 m/s
- High manufacturing repeatability

APPLICATIONS

Wind resource assessment, solar resource assessment as well as meteorology and environmental monitoring.

FEATURES

Sensor type	Tunnel Magneto Resistance						
Output signal	Analog						
Output range	05 V (0360°) 622 V						
Supply voltage							
Power consumption	< 0.75 mA						
Dead band	None						
Resolution	0.35°						
Accuracy	+/- 1.4°						
Miswire protection	Temperature fuse						
Response characteristics Starting threshold	< 0.4 m/s according to ASTM standards D5366-96						
ensor compatibility							
Compatible with	Orbit 360, EOL Zenith, all NRG loggers, Ammonit, Campbell						
Operating range							
perating range Measurement range	0 - 360°						
	0 - 360° -40+60 °C						
-							



Physical dimensions

Length	206 mm	
Height	230 mm	
Body diameter	35 mm	

Materials

Wing	Polycarbonate
Body	Corrosion resistant anodized aluminium
Bearing	Highly resistant ball bearings

Installation



Mounting	Onto a 25 mm tube
Connection	4 pin aviation plug
Cable recommendation	Signal cable 4x0.5 mm2 + shield
Tools required	2.5 mm allen wrench, electrical tape

Note: Male to Female Aviation Connector Socket.

SENSOR DIMENSIONS







CABLE RECOMMENDATION

Signal cable up to 150m: 4x0.5 mm² + shield. For longer cable, please consult sensor manufacturer.

SENSOR WIRING TABLE

Sensor Model	Sensor Pin		Kintech Colors		Orbit 360			EOL Zenith	
Sensor Model	36		Kintech Colors		Section	Terminal	Туре	Section	Terminal
Л	1	REF	•	Yellow	Analog Channels	47 51 55 59 64 68 72 76 80 87	(-)	DIR Analog Inputs	
	2	SIG	0	White	Analog Channels	48 52 56 60 65 69 73 77 81 84 85 86 90 91 92	Signal	DIR Analog Inputs	sig sig
	3	Us (+)	•	Green	Analog Channels	49 53 57 61 66 70 74 78 82 88	*(+)	BAT	Ð
Base sensor view / Soldering	4	GND		Brown	Analog Channels	47 51 55 59 64 68 72 76 80 87	(-)	BAT	-
connector view.		Shield		Yellow-Green	Power Input	Ŧ		BAT	Ŧ

Note:

Data logger hardware version < 3, (+) = Bat+ with current limited (12mA). Only 1 sensor must be powered on each output terminal.

Data logger hardware version \ge 3, (+) = Bat+ with current limited (50mA). Only 1 sensor must be powered on each output terminal.

Remember maximum power supply of this sensor is 22V.

Cost effective and protective packaging



For more information please contact web@kintech-engineering.com or visit our website www.kintech-engineering.com



REQUIRED DATA LOGGER VERSION

Minimum data logger required: ORBIT 360 BASIC PLUS. Minimum firmware required: any

HOW TO CONFIGURE IN ATLAS

Start Atlas and open the data logger you are working on. Now go to Site settings and scroll down to the Channels section and select the following type and model:

- Group: Analog channels
- Sensor Type: Windvane
- Sensor Model: Output 0-5V: Thies TMR / K360V

Important! Please make sure you are working with the latest version of Atlas. To check for new updates click the Check for updates button in the left-hand menu located in the main dashboard.

HOW TO CONFIGURE THIS SENSOR ON SITE

We recommend performing the entire sensor configuration using Atlas at the office before installing sensors onsite. Once the sensor is correctly setup in Atlas, use the Upload settings tool, to upload the sensor configuration to the data logger. In case you are already on site and need to configure the sensor directly on the data logger, follow these steps:

1. Turn on the data logger.

2. Using the keypad on the data logger, navigate the menu until you see Sensor model, then click the "right arrow" on the keypad.

- 3. Now scroll down to the channel you are going to connect the sensor to, and click the "right arrow" on the keypad.
- 4. Now click "Set" on the keypad and scroll up in the menu to set the sensor model type according to the table here below.
- Once you have found the correct sensor model, click the "right arrow" key twice to select it and save.
- 5. Click the "left arrow" several times to go back to the main menu.

Data logger model	Firmware version	Sensor model type on data logger				
Data logger model	Firmware version	Magnitude	Number	Name		
ORBIT 360	any	Wind direction	18	VANE Output 0-5V		
EOL ZENITH	EOL ZENITH any		08	Output 0-5V		

HOW TO CONFIGURE IN EOL MANAGER

Open EOL Manager and go to Settings of the data logger you are working on. Open the Inputs tab and select the following type and model:

- Group: Wind Vanes / Analog Inputs
- Sensor Type: Windvane
- Sensor Model: Output 0-5V

Last modified: 03.04.2023

