















ORNYTION 207 | WIND VANE

SENSOR WIRING TABLE

Sensor Model	Sensor Pin		Kintech Cable Colors		Orbit 360			EOL Zenith	
					Section	Terminal	Type	Section	Terminal
	C	GND		Brown	Analog Channels		(-)	Analog Inputs	
	B	SIG		White	Analog Channels		Signal	Analog Inputs	
	A	Us (+)		Green	Power Input		5V	Extra Analog	
		Shield		Yellow-Green	Power Input			Analog Inputs	
								BAT	

Note: Base sensor view / Soldering connector view.

*5V,  = Pulsating 5V with current limited (4mA). Only 1 sensor must be powered.

HOW TO CONFIGURE IN ATLAS

Open Atlas and go to the data logger you are working on. Scroll to the “channels” section and select the following type and model:

- Group: Analog channels
- Sensor Type: Windvane
- Sensor Model: **ORNYTION 207**

HOW TO CONFIGURE IN EOL MANAGER

Open EOL Manager and go to the data logger you are working on. Open the “inputs” tab and select the following type and model:

- Group: Wind Vanes / Analog Inputs
- Type: Windvane
- Model: **ORNYTION 207**

Last modified: 11.12.2019

For more information please contact support@kintech-engineering.com or visit our website www.kintech-engineering.com