























## SENSOR WIRING TABLE

Sensor Model	Sensor Pin Manufacturer Cable Colors		Kintech Colors		Orbit 360			EOL Zenith		
					Section	Terminal	Type	Section	Terminal	
		Blue	Supply (-)		Brown	Analog Channels		(-)	DIR	
		Yellow	Output (-)						Analog Inputs	
		Green	Signal		White	Analog Channels		Signal	DIR	
									Analog Inputs	
		Red	Supply (+)		Green	Analog Channels		*5V	DIR	
		Black	Shield		Yellow Green	Power Input			BAT	
	White	Do not connect								

Note: \*5V,  = Pulsating 5V with current limited (4mA). Only 1 sensor must be powered.

### HOW TO CONFIGURE IN ATLAS

Open Atlas and go to the data logger you are working on. Scroll to the “channels” section and select the following type and model:

- Group: Analog channels
- Sensor Type: Windvane
- Sensor Model: **VECTOR W200P**

### HOW TO CONFIGURE IN EOL MANAGER

Open EOL Manager and go to the data logger you are working on. Open the “inputs” tab and select the following type and model:

- Group: Wind Vanes / Analog Inputs
- Type: Windvane
- Model: **VECTOR W200P**

