











YOUNG 3102 | CUP ANEMOMETER

SENSOR WIRING TABLE

Sensor Model	Sensor Pin	Kintech Cable Colors		Orbit 360			EOL Zenith	
				Section	Terminal	Type	Section	Terminal
	Signal		White	Frequency Channels		Signal	Anemometer Inputs	
	Reference		Brown	Frequency Channels		(-)	Anemometer Inputs	
	Shield		Yellow Green	Power Input			BAT	

HOW TO CONFIGURE IN ATLAS

Open Atlas and go to the data logger you are working on. Scroll to the “channels” section and select the following type and model:

- Group: Frequency channels
- Sensor Type: Anemometer
- Sensor Model: **YOUNG 3102**

HOW TO CONFIGURE IN EOL MANAGER

Open EOL Manager and go to the data logger you are working on. Open the “inputs” tab and select the following type and model:

- Group: Anemometers/Frequency
- Type: Anemometer
- Model: **YOUNG 3102**

Last modified: 08.11.2019

